

Decoy Hauler Instructions

PARTS LIST

Item #	Qty	Description
1.	1	Plastic Marsh Brown Sled with tow rope
2.	1	Decoy Bag
3.	10	Small self tapping screws

Tools required

Drill and Phillips bit or Phillips screwdriver

1. Slide the decoy bag over the top of the sled with the mesh drain at the back of the sled.



2. Attach plastic trim lock to the lip of the sled. Bend the trimlock out so it will slip over and clip onto the lip of the sled. It must be opened up with your hand in order for it to fit onto the lip. Work your way down to the end once it has been started.











