



INSTRUCTIONS TO INSTALL BACKREST SPRINGS ON PREDATOR:

Tools needed for assembly will be 7/16" open end wrench and a 7/16 socket and extension.

PARTS LIST:

ITEM	PART	QTY
1	¼-20 X .75 lg bolt	2
2	Spring weldment	2
3	¼ inch washer	2
4	Nylock nut ¼-20	2
5	Predator unit	1

ASSEMBLY OF UNIT:

1. Put bolt (item 1) in thru hole in bottom of the spring (item 2).
2. Put spring into pocket on Predator (item 5) while aligning bolt (item 1) with the hole drilled in pocket on Predator.
3. Slide the washer (item 3) onto the bolt and then start threading on the nut (item 4) onto the bolt as well.
4. Using the socket with extension and open-end wrench tighten nut till snug against plastic.

