



## Pod Installation on Semi-V Boat




<u>Bottom Width</u>	<u>Pod size to use</u>
40"-46"	Small
47"-53"	Medium
54" and up	Large

16" between the pods is normally the very minimum amount required to be able to turn the motor without interference. Some Surface Drive motors may require more.

**SMALL PODS**



**MEDIUM PODS**



**LARGE PODS**

